


# Axial Resistor 1/4W 128value Engineering Kit J Tolarence

No.	PartNumber	Specification
1	RAXI-000J-1/4W000	Axial Resistor- 0Ω, 5%, 1/4W
2	RAXI-0R5J-1/4W0R5	Axial Resistor- 0.5Ω, 5%, 1/4W
3	RAXI-010J-1/4W1R0	Axial Resistor- 1Ω, 5%, 1/4W
4	RAXI-1R2J-1/4W1R2	Axial Resistor- 1.2Ω, 5%, 1/4W
5	RAXI-1R3J-1/4W1R3	Axial Resistor- 1.3Ω, 5%, 1/4W
6	RAXI-1R5J-1/4W1R5	Axial Resistor- 1.3Ω, 5%, 1/4W
7	RAXI-1R8J-1/4W1R8	Axial Resistor- 1.8Ω, 5%, 1/4W
8	RAXI-020J-1/4W2R0	Axial Resistor- 2Ω, 5%, 1/4W
9	RAXI-2R2J-1/4W2R2	Axial Resistor- 2.2Ω, 5%, 1/4W
10	RAXI-2R4J-1/4W2R4	Axial Resistor- 2.4Ω, 5%, 1/4W
11	RAXI-030J-1/4W3R0	Axial Resistor- 3Ω, 5%, 1/4W
12	RAXI-3R3J-1/4W3R3	Axial Resistor- 3.3Ω, 5%, 1/4W
13	RAXI-4R7J-1/4W4R7	Axial Resistor- 4.7Ω, 5%, 1/4W
14	RAXI-5R1J-1/4W5R1	Axial Resistor- 5.1Ω, 5%, 1/4W
15	RAXI-5R6J-1/4W5R6	Axial Resistor- 5.6Ω, 5%, 1/4W
16	RAXI-6R8J-1/4W6R8	Axial Resistor- 6.8Ω, 5%, 1/4W
17	RAXI-7R5J-1/4W7R5	Axial Resistor- 7.5Ω, 5%, 1/4W
18	RAXI-8R2J-1/4W8R2	Axial Resistor- 8.2Ω, 5%, 1/4W
19	RAXI-9R1J-1/4W9R1	Axial Resistor- 9.1Ω, 5%, 1/4W
20	RAXI-011J-1/4W100	Axial Resistor- 10Ω, 5%, 1/4W
21	RAXI-120J-1/4W120	Axial Resistor- 12Ω, 5%, 1/4W
22	RAXI-130J-1/4W130	Axial Resistor- 13Ω, 5%, 1/4W
23	RAXI-150J-1/4W150	Axial Resistor- 15Ω, 5%, 1/4W
24	RAXI-180J-1/4W180	Axial Resistor- 18Ω, 5%, 1/4W
25	RAXI-021J-1/4W200	Axial Resistor- 20Ω, 5%, 1/4W
26	RAXI-220J-1/4W220	Axial Resistor- 22Ω, 5%, 1/4W
27	RAXI-270J-1/4W270	Axial Resistor- 27Ω, 5%, 1/4W
28	RAXI-031J-1/4W300	Axial Resistor- 30Ω, 5%, 1/4W
29	RAXI-330J-1/4W330	Axial Resistor- 33Ω, 5%, 1/4W
30	RAXI-390J-1/4W390	Axial Resistor- 39Ω, 5%, 1/4W
31	RAXI-470J-1/4W470	Axial Resistor- 47Ω, 5%, 1/4W
32	RAXI-510J-1/4W510	Axial Resistor- 51Ω, 5%, 1/4W
33	RAXI-560J-1/4W560	Axial Resistor- 56Ω, 5%, 1/4W
34	RAXI-620J-1/4W620	Axial Resistor- 62Ω, 5%, 1/4W
35	RAXI-680J-1/4W680	Axial Resistor- 68Ω, 5%, 1/4W
36	RAXI-750J-1/4W750	Axial Resistor- 75Ω, 5%, 1/4W
37	RAXI-820J-1/4W820	Axial Resistor- 82Ω, 5%, 1/4W
38	RAXI-910J-1/4W910	Axial Resistor- 91Ω, 5%, 1/4W
39	RAXI-101J-1/4W101	Axial Resistor- 100Ω, 5%, 1/4W
40	RAXI-121J-1/4W121	Axial Resistor- 120Ω, 5%, 1/4W
41	RAXI-131J-1/4W131	Axial Resistor- 130Ω, 5%, 1/4W
42	RAXI-151J-1/4W151	Axial Resistor- 150Ω, 5%, 1/4W
43	RAXI-181J-1/4W181	Axial Resistor- 180Ω, 5%, 1/4W
44	RAXI-201J-1/4W201	Axial Resistor- 200Ω, 5%, 1/4W
45	RAXI-221J-1/4W221	Axial Resistor- 220Ω, 5%, 1/4W
46	RAXI-241J-1/4W241	Axial Resistor- 240Ω, 5%, 1/4W
47	RAXI-271J-1/4W271	Axial Resistor- 270Ω, 5%, 1/4W
48	RAXI-301J-1/4W301	Axial Resistor- 300Ω, 5%, 1/4W
49	RAXI-331J-1/4W331	Axial Resistor- 330Ω, 5%, 1/4W
50	RAXI-391J-1/4W391	Axial Resistor- 390Ω, 5%, 1/4W
51	RAXI-431J-1/4W431	Axial Resistor- 430Ω, 5%, 1/4W
52	RAXI-471J-1/4W471	Axial Resistor- 470Ω, 5%, 1/4W
53	RAXI-511J-1/4W511	Axial Resistor- 510Ω, 5%, 1/4W
54	RAXI-561J-1/4W561	Axial Resistor- 560Ω, 5%, 1/4W
55	RAXI-621J-1/4W621	Axial Resistor- 620Ω, 5%, 1/4W
56	RAXI-681J-1/4W681	Axial Resistor- 680Ω, 5%, 1/4W
57	RAXI-821J-1/4W821	Axial Resistor- 820Ω, 5%, 1/4W
58	RAXI-911J-1/4W911	Axial Resistor- 910Ω, 5%, 1/4W
59	RAXI-102J-1/4W102	Axial Resistor- 1KΩ, 5%, 1/4W
60	RAXI-122J-1/4W122	Axial Resistor- 1.2KΩ, 5%, 1/4W
61	RAXI-132J-1/4W132	Axial Resistor- 1.3KΩ, 5%, 1/4W
62	RAXI-152J-1/4W152	Axial Resistor- 1.5KΩ, 5%, 1/4W
63	RAXI-182J-1/4W182	Axial Resistor- 1.8KΩ, 5%, 1/4W
64	RAXI-202J-1/4W202	Axial Resistor- 2KΩ, 5%, 1/4W
65	RAXI-222J-1/4W222	Axial Resistor- 2.2KΩ, 5%, 1/4W
66	RAXI-242J-1/4W242	Axial Resistor- 2.4KΩ, 5%, 1/4W
67	RAXI-272J-1/4W272	Axial Resistor- 2.7KΩ, 5%, 1/4W
68	RAXI-302J-1/4W302	Axial Resistor- 3KΩ, 5%, 1/4W
69	RAXI-332J-1/4W332	Axial Resistor- 3.3KΩ, 5%, 1/4W
70	RAXI-392J-1/4W392	Axial Resistor- 3.9KΩ, 5%, 1/4W
71	RAXI-432J-1/4W432	Axial Resistor- 4.3KΩ, 5%, 1/4W
72	RAXI-472J-1/4W472	Axial Resistor- 4.7KΩ, 5%, 1/4W
73	RAXI-512J-1/4W512	Axial Resistor- 5.1KΩ, 5%, 1/4W
74	RAXI-562J-1/4W562	Axial Resistor- 5.6KΩ, 5%, 1/4W
75	RAXI-622J-1/4W622	Axial Resistor- 6.2KΩ, 5%, 1/4W
76	RAXI-682J-1/4W682	Axial Resistor- 6.8KΩ, 5%, 1/4W
77	RAXI-752J-1/4W752	Axial Resistor- 7.5KΩ, 5%, 1/4W
78	RAXI-822J-1/4W822	Axial Resistor- 8.2KΩ, 5%, 1/4W
79	RAXI-912J-1/4W912	Axial Resistor- 9.1KΩ, 5%, 1/4W
80	RAXI-103J-1/4W103	Axial Resistor- 10KΩ, 5%, 1/4W
81	RAXI-113J-1/4W113	Axial Resistor- 11KΩ, 5%, 1/4W
82	RAXI-123J-1/4W123	Axial Resistor- 12KΩ, 5%, 1/4W
83	RAXI-133J-1/4W133	Axial Resistor- 13KΩ, 5%, 1/4W
84	RAXI-153J-1/4W153	Axial Resistor- 15KΩ, 5%, 1/4W
85	RAXI-163J-1/4W163	Axial Resistor- 16KΩ, 5%, 1/4W
86	RAXI-183J-1/4W183	Axial Resistor- 18KΩ, 5%, 1/4W
87	RAXI-203J-1/4W203	Axial Resistor- 20KΩ, 5%, 1/4W

No.	PartNumber	Specification
88	RAXI-223J-1/4W223	Axial Resistor- 22KΩ, 5%, 1/4W
89	RAXI-243J-1/4W243	Axial Resistor- 24KΩ, 5%, 1/4W
90	RAXI-273J-1/4W273	Axial Resistor- 27KΩ, 5%, 1/4W
91	RAXI-303J-1/4W303	Axial Resistor- 30KΩ, 5%, 1/4W
92	RAXI-333J-1/4W333	Axial Resistor- 33KΩ, 5%, 1/4W
93	RAXI-393J-1/4W393	Axial Resistor- 39KΩ, 5%, 1/4W
94	RAXI-433J-1/4W433	Axial Resistor- 43KΩ, 5%, 1/4W
95	RAXI-473J-1/4W473	Axial Resistor- 47KΩ, 5%, 1/4W
96	RAXI-513J-1/4W513	Axial Resistor- 51KΩ, 5%, 1/4W
97	RAXI-563J-1/4W563	Axial Resistor- 56KΩ, 5%, 1/4W
98	RAXI-623J-1/4W623	Axial Resistor- 62KΩ, 5%, 1/4W
99	RAXI-683J-1/4W683	Axial Resistor- 68KΩ, 5%, 1/4W
100	RAXI-753J-1/4W753	Axial Resistor- 75KΩ, 5%, 1/4W
101	RAXI-823J-1/4W823	Axial Resistor- 82KΩ, 5%, 1/4W
102	RAXI-913J-1/4W913	Axial Resistor- 91KΩ, 5%, 1/4W
103	RAXI-104J-1/4W104	Axial Resistor- 100KΩ, 5%, 1/4W
104	RAXI-124J-1/4W124	Axial Resistor- 120KΩ, 5%, 1/4W
105	RAXI-134J-1/4W134	Axial Resistor- 130KΩ, 5%, 1/4W
106	RAXI-154J-1/4W154	Axial Resistor- 150KΩ, 5%, 1/4W
107	RAXI-184J-1/4W184	Axial Resistor- 180KΩ, 5%, 1/4W
108	RAXI-204J-1/4W204	Axial Resistor- 200KΩ, 5%, 1/4W
109	RAXI-224J-1/4W224	Axial Resistor- 220KΩ, 5%, 1/4W
110	RAXI-244J-1/4W244	Axial Resistor- 240KΩ, 5%, 1/4W
111	RAXI-274J-1/4W274	Axial Resistor- 270KΩ, 5%, 1/4W
112	RAXI-304J-1/4W304	Axial Resistor- 300KΩ, 5%, 1/4W
113	RAXI-334J-1/4W334	Axial Resistor- 330KΩ, 5%, 1/4W
114	RAXI-394J-1/4W394	Axial Resistor- 390KΩ, 5%, 1/4W
115	RAXI-434J-1/4W434	Axial Resistor- 430KΩ, 5%, 1/4W
116	RAXI-474J-1/4W474	Axial Resistor- 470KΩ, 5%, 1/4W
117	RAXI-514J-1/4W514	Axial Resistor- 510KΩ, 5%, 1/4W
118	RAXI-564J-1/4W564	Axial Resistor- 560KΩ, 5%, 1/4W
119	RAXI-624J-1/4W624	Axial Resistor- 620KΩ, 5%, 1/4W
120	RAXI-684J-1/4W684	Axial Resistor- 680KΩ, 5%, 1/4W
121	RAXI-754J-1/4W754	Axial Resistor- 750KΩ, 5%, 1/4W
122	RAXI-824J-1/4W824	Axial Resistor- 820KΩ, 5%, 1/4W
123	RAXI-914J-1/4W914	Axial Resistor- 910KΩ, 5%, 1/4W
124	RAXI-105J-1/4W105	Axial Resistor- 1MΩ, 5%, 1/4W
125	RAXI-135J-1/4W135	Axial Resistor- 1.3MΩ, 5%, 1/4W
126	RAXI-515J-1/4W225	Axial Resistor- 2.2MΩ, 5%, 1/4W
127	RAXI-225J-1/4W515	Axial Resistor- 5.1MΩ, 5%, 1/4W
128	RAXI-106J-1/4W106	Axial Resistor- 10MΩ, 5%, 1/4W

## 고정저항기 • 색 정격 표시 (4색대로 표시경우)



색 명	제 1 색 대	제 2 색 대	제 3 색 대	제 4 색 대
	제 4 숫 자	제 4 숫 자	제 4 숫 자	제 4 숫 자
흑	0	0	10 <sup>0</sup> (100Ω 대)	-
갈	1	1	10 <sup>1</sup> (1kΩ 대)	± 1%(F)
적	2	2	10 <sup>2</sup> (10kΩ 대)	±%(G)
등	3	3	10 <sup>3</sup> (100kΩ 대)	-
황	3	3	10 <sup>4</sup> (1MΩ 대)	-
록	5	5	10 <sup>5</sup> (10MΩ 대)	±0.5%(D)
청	6	6	10 <sup>6</sup>	± 0.25%(C)
보	7	7	10 <sup>7</sup>	± 0.1%(B)
회	8	8	10 <sup>8</sup>	±0.05%(A)
백	9	9	10 <sup>9</sup>	± 1%
금	-	-	10 <sup>-1</sup> (10kΩ 대)	± 1%
은	-	-	10 <sup>-2</sup> (1kΩ 대)	± 1%